





VW Lupo Seat Arosa

Montageanleitung
Mounting instructions
Instructions de montage
Monteringsanvisning
Montagehandleiding
Instrucciones de montaje
Istruzioni di montaggio
Asennusohjeet



(F)

S = AR
B = stop
BL = clignotant
ZR = recul de complément
NES = AR de brouillard
R = catadioptré

(S)

S = bakljus
B = bromsljus
BL = blinkljus
ZR = backljus
NES = dimbak
R = reflex

(NL)

S = achterlicht
B = remlicht
BL = knipperlicht
ZR = achterruitrijlamp
NES = mistachterlicht
R = reflector

(E)

S = luz trasera
B = luz de freno
BL = luz intermitente
ZR = luz marcha atrás
NES = luz trasera antiniebla
R = reflector trasero

(D)

S = Schlußlicht
B = Bremslicht
BL = Blinklicht
ZR = Zusatzrückfahrlicht
NES = Nebelschlußlicht
R = Rückstrahler

(GB)





S = tail light
B = brake light
BL = flasher light
ZR = aux. reversing light
NES = rear fog light
R = reflex reflector

(I)

S = luce posteriore
B = luce d'arresto
BL = luce intermittente
ZR = luce retromarcia
NES = luce retronebbia
R = catadiottro

(FIN)

S = takavallo
B = jarruvalo
BL = vilkkuvalo
ZR = lisäperuutusvalo
NES = takasumovalo
R = heijastin



VW Lupo
Seat Arosa → 12.2000

