

BG

Ръководство за инсталиране
Електрическа горивна помпа Bosch

CZ

Návod k instalaci
Elektrické palivové čerpadlo Bosch

D

Installationsanleitung
Bosch Elektro-Kraftstoffpumpe

E

Instrucciones de instalación
Bomba de combustible eléctrica Bosch

F

Instructions d'installation
Pompe électrique à carburant Bosch

GB

Installation instructions
Bosch electric fuel pump

H

Telepítési útmutató
Bosch elektromos üzemanyag-szivattyú

I

Istruzioni per l'installazione
Elettropompa carburante Bosch

J








取付説明書
Bosch 電動フューエルポンプ



BOSCH



Нагнетателен горивен модул
Podávací modul paliva
Kraftstofffördermodul
Módulo de suministro de combustible
Module d'alimentation en carburant
Fuel delivery module
Üzemanyagszállító modul
Modulo di alimentazione del carburante
フューエル フィードモジュール



NL

Installatiehandleiding

Elektrische brandstofpomp van Bosch

P

Instruções de instalação

Bomba de combustível elétrica Bosch

PL

Instrukcja montażu

Elektryczna pompa paliwa Bosch

RC

安装说明

博世电动燃油泵

RO

Instrucțiuni de utilizare

Pompă electrică de carburant Bosch

RUS

Руководство по установке

Электрический топливный насос Bosch

S

Installationsinstruktion

Bosch elbränslepumpar

SK

Návod na montáž

Elektrické palivové čerpadlo Bosch

TR

Kurulum talimatı

Bosch elektro yakıt pompası



Brandstofopvoermodule
Módulo de alimentação de combustível

Zespół tłoczący paliwo
供油模块





Modul de pompare a carburantului

Модуль подачи топлива

Bränsletillförselmodul

Modul palivového čerpadla

Yakıt basma modülü



BOSCH

