PIFOR	BOSCH Delphi Diesel Center Technologies	DENSO	Stanadyne	YANMAI
BY 1	HII			

Product specific information Programming Yes Calibration code (5 characters) Unlocking No Adaption values reset No Bleed adjustment at mounting 1 No adjustment at mounting 2 - Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions Replace sealing washer	Product info sh	et \	/DO	A2C59511364
Programming Ves Calibration code (5 characters) Unlocking Adaption values reset No Bleed adjustment at mounting_1 No Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions	Special tools needed?	No		
Programming Ves Calibration code (5 characters) Unlocking Adaption values reset No Bleed adjustment at mounting_1 No Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions				
Programming Ves Calibration code (5 characters) Unlocking Adaption values reset No Bleed adjustment at mounting_1 No Tightening torques Injector/ retaining clamp High Pressure pipe nuts Assembly instructions				
Programming Ves Calibration code (5 characters) Unlocking Adaption values reset No Bleed adjustment at mounting_1 No Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions				
Unlocking Adaption values reset No Bleed adjustment at mounting_1 No Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions		Product	specific information	on
Adaption values reset No No Bleed No adjustment at mounting_1 No Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions	Programming	Yes Cali	bration code (5 characters)	Aport Disage
Adaption values reset No No Bleed No adjustment at mounting_1 No Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions				01905 MA
Bleed adjustment at mounting_1 No adjustment at mounting_2 Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions				
adjustment at mounting_1 No adjustment at mounting_2 Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions				
Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions				
Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions	adjustificht at mounting_1	140		
Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions				
Tightening torques Injector/ retainingclamp High Pressure pipe nuts Assembly instructions				
Injector/ retaining clamp High Pressure pipe nuts 30 Nm Assembly instructions	adjustment at mounting_2			
Injector/ retaining clamp High Pressure pipe nuts 30 Nm Assembly instructions				
Injector/ retaining clamp High Pressure pipe nuts 30 Nm Assembly instructions				
Injector/ retaining clamp High Pressure pipe nuts 30 Nm Assembly instructions		 Τίσ	htening torques	
High Pressure pipe nuts 30 Nm Assembly instructions	Injector/ retaining clamp	118		
Assembly instructions				
				// //
Replace sealing washer		Asse	embly instructions	
mephase seaming meaning	Replace sealing washer			
Core charge terms:	Core charge terms:			
-externally intact,	externally intact,			
-no mechanical damage,				
-not dismantled, -no heavy corrosion.				